



# HA87429391 KIT [CREE LED Hi-Lo Beam Corner Headlight Kit, 9000 Lumens]

## Instruction Guide

This kit is equipped with a second hi-lo beam jumper harness for use in STX applications

**NOTE:** Some models will have wiring for both halogen and HID style lights. Be sure to use the proper connector to power your new LED light

- If replacing a HID light, also remove the ballast. The connector leading to the ballast should be used to power the new LED.
- Models with OE halogen lights will have an additional unused electrical connector that was intended for HID equipped models. Remove the cap from this connector and connect it to the new light

### **Hood Mounted Lights:**

1. Raise hood & remove bolts in covering plate
2. Remove covering plate to gain access to rear of light
3. Remove bolts from light and disconnect wiring connector
4. Remove light from bezel in the hood
5. Place new light into the bezel
6. Connect wiring harness (see note above)
7. Replace covering plate and bolts

### **Frame Mounted Lights:**

1. Open front grille, lower/release the catch plate on the underside of the machine
2. Remove (3) bolts holding the lever & support in place, carefully move support to side
3. Remove (4) bolts from rear OE light
4. Disconnect wiring, remove light from cavity in frame
5. Remove any foam that remains in the cavity area for proper ventilation
6. Place new light into cavity. Some machines may have to separate mounting hole options. The new light mounting bolts should go through the upper holes
7. Install washer and nuts to light, secure
8. Attach the wiring connectors (see note above)
9. Replace lever support and bolts, re-attach lower catch plate