



HA87309031 KIT [CREE LED Hi-Lo Beam Corner Headlight Kit]

Instruction Guide

Instructions for Installation on Case IH Tractors: 180 Magnum, 190 Magnum, 240 Magnum, 245 Magnum, 250 Magnum, 255 Magnum, 260 Magnum, 275 Magnum, 280 Magnum, 290 Magnum, 305 Magnum, 310 Magnum, 315 Magnum, 335 Magnum, 340 Magnum, 370 Magnum, 380 Magnum, MX215, MX245, MX275, MX305

Case IH Sprayers: 2240 Patriot, 2250 Patriot, 3240 Patriot, 3340 Patriot, 4440 Patriot, 5550 Trident

Steiger Tractors: 350, 370, 400, 420, 450, 470, 500, 540, 550, 580, 600, 620

1. Disconnect wiring connector from light
2. Remove 3 screws in plates that connect center and corner light
3. Remove 4 mounting bolts and remove light
4. Install new Hy-Cap light into grille and replace 4 mount bolts (New bolts have been supplied with new lights)
5. Replace 3 screws into connecting plate (New bolts have been supplied with new lights)
6. Once light is positioned properly, secure lights by tightening all hardware
7. Attach electrical connectors
8. Repeat steps 1-7 for both lights

Instructions for Installation on Case IH Tractor Models: 170 Puma, 170 Puma CVT, 170 Puma CVX, 180 Puma, 180 Puma CVT, 180 Puma CVX, 185 Puma, 185 Puma CTV, 185 Puma CVX, 195 Puma, 195 CVT, 195 Puma CVX, 200 Puma, 200 Puma CVT, 200 Puma CVX, 210 Puma, 210 Puma CVT, 210 Puma CVX, 215 Puma, 215 Puma CVT, 215 Puma CVX, 220 Puma, 220 Puma CVT, 220 Puma CVX, 225 Puma CVT, 225 Puma CVX, 230 Puma CVT, 230 Puma CVX, 240 Puma CVT, 240 Puma CVX

1. Disconnect wiring connectors from light
2. There is a plate joining the lights together. Remove 3 screws from the plate to release light
3. Remove 4 mounting bolts that hold light in place and remove light from grille
4. Install new Hy-Cap light into grille and replace 4 mount bolts (New bolts have been supplied with new lights)
5. Replace 3 screws into connecting plate (New bolts have been supplied with new lights)
6. Once light is positioned properly, secure lights by tightening all hardware
7. Attach blue electrical connector to power light
8. Replace Plastic Panel
9. The original light contained a side light that will no longer be needed (The connection can be covered or sealed with electrical tape or wire nut)
10. Repeat steps 1-7 for both lights

